

Disable Aid for Toilet



Find a steel frame chair with armrests. I found one on the Nature Strip free recycling program.



Cut the legs to reduce height to suit the toilet ('1'). Remove the back at '2'.

It is a good idea to reinforce the corners at '3' using the offcuts. Bend at '4' using a pipe or tube bender to widen the back. If you do not have a pipe bender, party cut and re-weld at '4'. Glue some rubber or foam on the inside to protect the toilet bowl at '4'.

